

Sets for Sony BURANO

Basic Cine Set for Sony BURANO

Consists of:

| | |
|---------------------------------|------------|
| Top Plate for Sony BURANO | K2.0049751 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Bridge Plate Adapter BPA-5 | K2.0017138 |
| 15mm LWS Rod Console | K2.65264.0 |
| Support Rods 240mm/9.4in, Ø15mm | K2.66253.0 |

[KK.0050113](#)

Basic Broadcast Set for Sony BURANO

Consists of:

| | |
|----------------------------------|------------|
| Top Plate for Sony BURANO | K2.0049751 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Broadcast Shoulder Adapter BSA-1 | K2.0043749 |
| 15mm LWS Rod Console | K2.65264.0 |
| Support Rods 240mm/9.4in, Ø15mm | K2.66253.0 |

[KK.0050114](#)

Pro Cine Set for Sony BURANO

Consists of:

| | |
|---|------------|
| Top Plate for Sony BURANO | K2.0049751 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Side Bracket Right for Sony BURANO | K2.0049819 |
| Side Bracket Left for Sony BURANO | K2.0049816 |
| Rear Side Bracket Right for Sony BURANO | K2.0049904 |
| NATO Rail Clamp NRC-1 | K2.0047776 |
| NATO Rail Clamp NRC-2 | K2.0048324 |
| Center Camera Handle CCH-4 | K2.0017270 |
| Bridge Plate Adapter BPA-5 | K2.0017138 |
| 15mm Reduction Insert (2x) | K2.66255.0 |
| 15mm LWS Rod Console | K2.65264.0 |
| Support Rods 240mm/9.4in, Ø15mm | K2.66253.0 |
| Rod Mounting Bracket RMB-3 | K2.0006186 |

[KK.0050115](#)

Pro Broadcast Set for Sony BURANO

Consists of:

| | |
|---|------------|
| Top Plate for Sony BURANO | K2.0049751 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Side Bracket Right for Sony BURANO | K2.0049819 |
| Side Bracket Left for Sony BURANO | K2.0049816 |
| Rear Side Bracket Right for Sony BURANO | K2.0049904 |
| NATO Rail Clamp NRC-1 | K2.0047776 |
| NATO Rail Clamp NRC-2 | K2.0048324 |
| Center Camera Handle CCH-4 | K2.0017270 |
| Broadcast Shoulder Adapter BSA-1 | K2.0043749 |
| 15mm Reduction Insert (2x) | K2.66255.0 |
| 15mm LWS Rod Console | K2.65264.0 |
| Support Rods 240mm/9.4in, Ø15mm | K2.66253.0 |
| Rod Mounting Bracket RMB-3 | K2.0006186 |

[KK.0050116](#)

Parts for Sony BURANO



Top Plate for Sony BURANO, [K2.0049751](#)



Side Bracket Left for Sony BURANO [K2.0049816](#)



Side Bracket Right for Sony BURANO, [K2.0049819](#)



Rear Side Bracket Right for Sony BURANO [K2.0049904](#)



NATO Rail Clamp NRC-1, [K2.0047776](#)



NATO Rail Clamp NRC-2, [K2.0048324](#)

Sets and parts for Sony Venice 1/2

Basic Cine Set for Sony Venice 1/2

Consists of:

| | |
|---------------------------------|------------|
| Top Plate for Sony Venice 1/2 | K2.0043699 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Support Rods 340mm/9.4in, Ø15mm | K2.66252.0 |
| Bridge Plate Adapter BPA-5 | K2.0017138 |
| Center Camera Handle CCH-4 | K2.0017270 |

[KK.0043758](#)

Pro Cine Set for Sony Venice 1/2

Consists of:

| | |
|---|------------|
| Top Plate for Sony Venice 1/2 | K2.0043699 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Support Rods 340mm/9.4in, Ø15mm | K2.66252.0 |
| Bridge Plate Adapter BPA-5 | K2.0017138 |
| Side Bracket Right for Sony Venice 1/2 | K2.0043731 |
| Side Bracket Left for Sony Venice 1/2 | K2.0043725 |
| Center Camera Handle CCH-4 | K2.0017270 |
| EVF Bracket for Sony DVF-EL200 (Venice) | K2.0021525 |
| Mini Viewfinder Bracket MVB-1 | K2.0006140 |

[KK.0043759](#)

Sets and parts for Sony Venice Extension Unit 1/2

Basic Set for Venice Extension Unit 1/2

Consists of:

| | |
|---|------------|
| Base Plate for Venice Ext. Unit | K2.0024564 |
| Top Plate for Venice Ext. Unit | K2.0039457 |
| Side Bracket Right for Venice Ext. Unit | K2.0024566 |
| Side Bracket Left for Venice Ext. Unit | K2.0024761 |
| Cable Clamp for Venice Ext. Unit | K2.0024569 |
| Back Plate for Venice Ext. Unit | K2.0024573 |
| Rosette Adapters, RA-6, pair | K2.0024574 |
| Back Plate 2 for Venice Ext. Unit | K2.0047941 |

[KK.0047971](#)

Base Plate for Venice Ext. Unit, [K2.0024564](#)



Top Plate for Venice Ext. Unit, [K2.0039457](#)



Cable Clamp for Venice Ext. Unit [K2.0024569](#)



Back Plate for Venice Ext. Unit [K2.0024573](#)



Back Plate 2 for Venice Ext. Unit [K2.0047941](#)



Side Bracket Left for Venice Ext. Unit [K2.0024761](#)



Side Bracket Right for Venice Ext. Unit [K2.0024566](#)



Top Plate for Sony Venice 1/2 [K2.0043699](#)



Plate for Sony Venice 1/2 [K2.0043726](#)



Broadcast Shoulder Adapter BSA-1 [K2.0043749](#)



Basic Broadcast Set for Sony Venice 1/2

Consists of:

| | |
|----------------------------------|------------|
| Top Plate for Sony Venice 1/2 | K2.0043699 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Support Rods 340mm/9.4in, Ø15mm | K2.66252.0 |
| Broadcast Shoulder Adapter BSA-1 | K2.0043749 |
| Center Camera Handle CCH-4 | K2.0017270 |

[KK.0043757](#)

Pro Broadcast Set for Sony Venice 1/2

Consists of:

| | |
|---|------------|
| Top Plate for Sony Venice 1/2 | K2.0043699 |
| Plate for Sony Venice 1/2 | K2.0043726 |
| Support Rods 340mm/9.4in, Ø15mm | K2.66252.0 |
| Broadcast Shoulder Adapter BSA-1 | K2.0043749 |
| Side Bracket Right for Sony Venice 1/2 | K2.0043731 |
| Side Bracket Left for Sony Venice 1/2 | K2.0043725 |
| Center Camera Handle CCH-4 | K2.0017270 |
| EVF Bracket for Sony DVF-EL200 (Venice) | K2.0021525 |
| Mini Viewfinder Bracket MVB-1 | K2.0006140 |

[KK.0043753](#)

Side Bracket Right for Sony Venice 1/2 [K2.0043731](#)



Side Bracket Left for Sony Venice 1/2 [K2.0043725](#)



Rosette Adapter RA-6 (pair) [K2.0024574](#)

