



SNAPGRID[®] for ARRI[®] SKYPANEL[®] SNAPBAG[®] S360, S120, S60 and S30 OPERATING INSTRUCTIONS – BEDIENUNGSANLEITUNG

PLEASE ALSO REFER TO THE LUMINAIRE INSTRUCTIONS REGARDING USE OF ACCESSORIES.

L2.0020279 / SGA360SB40

L2.0010381 / SGA120SB40

L2.0008143 / SGA60SB40

L2.0008140 / SGA30SB40

L2.0020275 / SGA04W40

L2.0020276 / SGA05W40

L2.0020277 / SGA07W40



Open the SNAPGRID[®] and attach it with the hook and loop into the SNAPBAG[®].

MOUNTING POINT FOR THE SAFETY CABLE

Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.



Read also our additional safety & handling instructions:
www.dopchoice.com/instruction



SNAPGRID[®] for ARRI[®] SKYPANEL[®] S120, S60 and S30

OPERATING INSTRUCTIONS – BEDIENUNGSANLEITUNG

PLEASE ALSO REFER TO THE LUMINAIRE INSTRUCTIONS REGARDING USE OF ACCESSORIES.

L2.0010382 / SGA120P4060

L2.0008144 / SGA60P40

L2.0008142 / SGA30P40



**MOUNTING POINT FOR
THE SAFETY CABLE**
Always secure the
accessory with a
suitable safety cable
from falling when the
primary mounting
method fails.

**Pull the elastics on all 4 corners
over the 4 blue blocks.**



**Read also our additional safety & handling instructions:
www.dopchoice.com/instruction**