


General Overview TRINITY 2 / ARTEMIS 2



Configuration Overview | 8.0.0 / 2023.05

ARTEMIS 2 / TRINITY 2 Overview



Batteries



BMS-2, Battery Mounting Base, Gen.2, (naked), [K2.0039300](#) for ARTEMIS 2 / TRINITY 2

BMS-1, Battery Mounting Base, Gen.2, (naked), [K2.0037707](#) for artemis Gen.1 / TRINITY Gen.1



B-Mount for BMS-2, [K2.0040284](#)



V-Mount for BMS-1 / BMS-2, [K2.0040286](#)



G-Mount for BMS-1 / BMS-2, [K2.0040285](#)