

Handle Support

Handle Extension Set

Consists of:
Includes:
Handle Extension HEX-1
Handle Extension HEX-2
Handle Extension HEX-3
Handle Extension HEX-4
Handle Extension HEX-5
Handle Extension HEX-90
Wooden Shell for HEX
Plastic Shell for HEX

[KK.0037820](#)

Includes:
K2.0019791
K2.0019792
K2.0019797
K2.0019798
K2.0036917
K2.0019810
K2.0037131
K2.0037132



Handle Extension HEX-1
[K2.0019791](#)



Handle Extension HEX-2
[K2.0019792](#)



Handle Extension HEX-3
[K2.0019797](#)



Handle Extension HEX-4
[K2.0019798](#)



Handle Extension HEX-5
[K2.0036917](#)



Handle Extension HEX-90
[K2.0019810](#)



Wooden Shell for HEX
[K2.0037131](#)



Plastic Shell for HEX
[K2.0037132](#)



Handle Extension Block, HEB-1, [K2.0001016](#)



Handle Extension Block long, HEB-3, [K2.0001017](#)



Bicycle Grip Adapter BGA-1
[K2.0034248](#)



Bicycle Grip Adapter BGA-2
[K2.0036623](#)

Top Handles



Cage Top Handle, CTH-1
[K2.66227.0](#)



Center Camera Handle CCH-2
[K2.73002.0](#)



Camera Center Handle CCH-4
[K2.0017270](#)



CCH-2 Support, [K2.0038176](#)

Handgrip Accessories



Standard Grip Left SGL-1, [K2.0016317](#)



Standard Grip Right SGR-1, [K2.0016318](#)



Standard righthand articulating Handgrip
[K2.45886.0](#)



Handgrip without on/off switch,
[K2.47861.0](#)



Handgrip with on/off switch RS-3 pin,
[K2.47862.0](#)



Handgrip with on/off switch Hirose 4-pin,
[K2.66278.0](#)



Handgrip Extension 80 mm, [K2.0012913](#)



Handgrip Extension 160 mm, [K2.0012911](#)



Handgrip Extension 240 mm, [K2.0012917](#)



Extension Tube
[K2.47136.0](#)



Extension Spacer 50 mm, [K2.0013615](#)



15 mm Cable Clip
[K2.0012921](#)

Handgrip Sets



UBS-3 Handgrip Set without on/off
Consists of:
Handgrip without on/off switch
Handgrip Extension long
Universal Bridge Support, UBS-3
[KK.0005675](#)
K2.47861.0 (2x)
K2.47863.0 (2x)
K2.0013320 (1x)



UBS-3 Handgrip Set on/off RS 3-pin
Consists of:
Handgrip without on/off switch
Handgrip with on/off switch RS 3-pin
Handgrip Extension long
Universal Bridge Support, UBS-3
[KK.0005677](#)
K2.47861.0 (1x)
K2.47862.0 (1x)
K2.47863.0 (2x)
K2.0013320 (1x)



UBS-2 Handgrip Set on/off Hirose 4-pin
Consists of:
Handgrip without on/off switch
Handgrip with on/off switch Hirose 4-pin
Handgrip Extension long
Universal Bridge Support, UBS-2
[KK.0005679](#)
K2.47861.0 (1x)
K2.66278.0 (1x)
K2.47863.0 (2x)
K2.66277.0 (1x)



Handgrip Set Right
Consists of:
Articulating Camera Handgrip
Handgrip Extension long
[KK.0005710](#)
K2.45886.0 (1x)
K2.47863.0 (1x)



Articulating Handgrip Set
Consists of:
Articulating Handgrip Right
Articulating Handgrip Left
[K2.0001021](#)
K4.54521.0 (1x)
K4.54523.0 (1x)



LBS-2 Handgrip Set without on/off
Consists of:
Handgrip without on/off switch
Handgrip Extension long
Lightweight Bridge Support, LBS-2
[KK.0005674](#)
K2.47861.0 (2x)
K2.47863.0 (2x)
K2.66275.0 (1x)



LBS-2 Handgrip Set on/off RS 3-pin
Consists of:
Handgrip without on/off switch
Handgrip with on/off switch RS 3-pin
Handgrip Extension long
Lightweight Bridge Support, LBS-2
[KK.0005676](#)
K2.47861.0 (1x)
K2.47862.0 (1x)
K2.47863.0 (2x)
K2.66275.0 (1x)



LBS-2 Handgrip Set on/off Hirose 4-pin
Consists of:
Handgrip without on/off switch
Handgrip with on/off switch Hirose 4-pin
Handgrip Extension long
Lightweight Bridge Support, LBS-2
[KK.0005678](#)
K2.47861.0 (1x)
K2.66278.0 (1x)
K2.47863.0 (2x)
K2.66275.0 (1x)



Handgrip Set
Consists of:
Articulating Handgrip Set
Extension Tube for Handgrip
Handgrip Extension short
[KK.0005821](#)
K2.0001021 (1x)
K2.47136.0 (2x)
K2.47648.0 (2x)

**** discontinued items
no stock available anymore**