

Sets for Sony FS7II/FX9



Basic Set for Sony FS7II/FX9

Consists of:
 Top Plate for Sony FS7II/ FX9
 Plate for Sony FS7II/ FX9
 Lens Adapter Support LAS-1
 Support Rods 240mm/9.4in, Ø15mm
 15mm LWS Rod Console

[KK.0035874](#)

Pro Set for Sony FS7II/FX9

Consists of:
 Plate for Sony FS7II/ FX9
 Top Plate for Sony FS7II/ FX9
 Lens Adapter Support LAS-1
 E- to PL-Mount Support for Vocas
 Side Bracket Right for Sony FS7II/FX9
 Side Bracket Left for Sony FS7II/FX9
 Viewfinder Bracket for Sony FS7II/ FX9
 Camera Center Handle CCH-4
 Sliding Adapter for CCH-4
 Rod Mounting Bracket RMB-3
 15mm Reduction Insert
 15mm LWS Rod Console
 Support Rods 240mm/9.4in, Ø15mm

[KK.0035875](#)



Viewfinder Bracket for Sony FS7II/FX9, [K2.0034657](#)



Plate for Sony FS7II/FX9 [K2.0035830](#)



Top Plate for Sony FS7II/ FX9, [K2.0034691](#)



E- to PL-Mount Support for Vocas [K2.0034700](#)



Side Bracket Right for Sony FS7II/FX9 [K2.0034709](#)



Side Bracket Left for Sony FS7II/FX9, [K2.0034727](#)

Sets for Sony PXW-FS7 / FS7 II **



Basic Set for Sony PXW-FS7 / FS7 II **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm

[KK.0006716](#)

Top/Bottom Sony Viewfinder Set for Sony PXW-FS7 / FS7 II **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7

[KK.0006717](#)

Pro Set for Sony PXW-FS7 / FS7 II **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7
 Center Camera Handle, CCH-2
 Viewfinder Bracket for Sony PXW-FS7
 15 mm LWS Rod Console
 Support Rods 140 mm Ø 15mm

[KK.0006718](#)

Pro Set for Sony PXW-FS7/ FS7 II / BP-8 **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7
 Center Camera Handle, CCH-2
 Viewfinder Bracket for Sony PXW-FS7
 15 mm LWS Rod Console
 Support Rods 140 mm Ø 15mm
 Bridge Plate BP-8 Set (19 mm Rods)

[KK.0006719](#)

Pro Set for Sony PXW-FS7/ FS7 II / BP-9 **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7
 Center Camera Handle, CCH-2
 Viewfinder Bracket for Sony PXW-FS7
 15 mm LWS Rod Console
 Support Rods 140 mm Ø 15mm
 Bridge Plate BP-9 Set (15 mm Rods)

[KK.0006720](#)



Adapter Plate for Sony PXW-FS7/ FS7 II, [K2.0003684](#) **



Top Plate for Sony PXW-FS7 / FS7 II, [K2.0003722](#) **



Viewfinder Bracket for Sony PXW-FS7/ FS7 II, [K2.0003749](#) **



Lens Adapter Support LAS-1, [K2.0003899](#) **

Sets for Sony Sony a7s II / Sony a7r II**

Basic Set for Sony a7s II

Consists of:
 Base Plate for Sony a7s II
 Lens Adapter Support LAS-1
 Side Bracket left for Sony a7s II
 Cable Clamp for Sony a7s II
 Cage Top Handle CTH-1
 Support Rods 240 mm (9.4 inch), Ø 15 mm

[KK.0010057](#)

Pro Set for Sony a7s II

Consists of:
 Base Plate for Sony a7s II
 Lens Adapter Support LAS-1
 Side Bracket left for Sony a7s II
 Cable Clamp for Sony a7s II
 Side Bracket right for Sony a7s II
 Cage Top Handle CTH-1
 Support Rods 240 mm (9.4 inch), Ø 15 mm
 Bridge plate adapter for ALEXA Mini (BPA-4)
 Bridge Plate Sled, BPS-2
 Bottom dove-tail plate 300 mm/12 inch
 Rod mounting bracket (RMB-3)
 Viewfinder Cross Pipe

[KK.0010079](#)



Base Plate for Sony a7s II [K2.0009468](#)



Cable Clamp for Sony a7s II [K2.0009646](#)



Side Bracket left for Sony a7s II [K2.0009440](#)



Side Bracket right for Sony a7s II [K2.0009455](#)



Viewfinder Cross Pipe, [K2.0013302](#)

** discontinued items
 no stock available anymore