

Sets for Sony FS7II/FX9



Basic Set for Sony FS7II/FX9

Consists of:
 Top Plate for Sony FS7II/ FX9
 Plate for Sony FS7II/ FX9
 Lens Adapter Support LAS-1
 Support Rods 240mm/9.4in, Ø15mm
 15mm LWS Rod Console

KK.0035874

K2.0034691
 K2.0035830
 K2.0003899
 K2.66253.0
 K2.65264.0

Pro Set for Sony FS7II/FX9

Consists of:
 Plate for Sony FS7II/ FX9
 Top Plate for Sony FS7II/ FX9
 Lens Adapter Support LAS-1
 E- to PL-Mount Support for Vocas
 Side Bracket Right for Sony FS7II/FX9
 Side Bracket Left for Sony FS7II/FX9
 Viewfinder Bracket for Sony FS7II/ FX9
 Camera Center Handle CCH-4
 Sliding Adapter for CCH-4
 Rod Mounting Bracket RMB-3
 15mm Reduction Insert
 15mm LWS Rod Console
 Support Rods 240mm/9.4in, Ø15mm

KK.0035875

K2.0035830
 K2.0034691
 K2.0003899
 K2.0034700
 K2.0034709
 K2.0034727
 K2.0034657
 K2.0017270
 K2.0019282
 K2.0006186
 K2.66255.0
 K2.65264.0
 K2.66253.0



Viewfinder Bracket for Sony FS7II/FX9, K2.0034657



Plate for Sony FS7II/FX9 K2.0035830



Top Plate for Sony FS7II/ FX9, K2.0034691



E- to PL-Mount Support for Vocas K2.0034700



Side Bracket Right for Sony FS7II/FX9 K2.0034709



Side Bracket Left for Sony FS7II/FX9, K2.0034727

Sets for Sony PXW-FS7 / FS7 II **



Basic Set for Sony PXW-FS7 / FS7 II **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm

KK.0006716

K2.0003684
 K2.0003899
 K2.66253.0

Top/Bottom Sony Viewfinder Set for Sony PXW-FS7 / FS7 II **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7

KK.0006717

K2.0003684
 K2.0003899
 K2.66253.0
 K2.0003722

Pro Set for Sony PXW-FS7 / FS7 II **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7
 Center Camera Handle, CCH-2
 Viewfinder Bracket for Sony PXW-FS7
 15 mm LWS Rod Console
 Support Rods 140 mm Ø 15mm

KK.0006718

K2.0003684
 K2.0003899
 K2.66253.0
 K2.0003722
 K2.73002.0
 K2.0003749
 K2.65264.0
 K2.66254.0

Pro Set for Sony PXW-FS7/ FS7 II / BP-8 **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7
 Center Camera Handle, CCH-2
 Viewfinder Bracket for Sony PXW-FS7
 15 mm LWS Rod Console
 Support Rods 140 mm Ø 15mm
 Bridge Plate BP-8 Set (19 mm Rods)

KK.0006719

K2.0003684
 K2.0003899
 K2.66253.0
 K2.0003722
 K2.73002.0
 K2.0003749
 K2.65264.0
 K2.66254.0
 K2.47090.0

Pro Set for Sony PXW-FS7/ FS7 II / BP-9 **

Consists of:
 Adapter Plate for Sony PXW-FS7
 Lens Adapter Support LAS-1
 Support Rods 240 mm Ø 15mm
 Top Plate for Sony PXW-FS7
 Center Camera Handle, CCH-2
 Viewfinder Bracket for Sony PXW-FS7
 15 mm LWS Rod Console
 Support Rods 140 mm Ø 15mm
 Bridge Plate BP-9 Set (15 mm Rods)

KK.0006720

K2.0003684
 K2.0003899
 K2.66253.0
 K2.0003722
 K2.73002.0
 K2.0003749
 K2.65264.0
 K2.66254.0
 K2.47091.0



Adapter Plate for Sony PXW-FS7/ FS7 II, K2.0003684 **



Top Plate for Sony PXW-FS7 / FS7 II, K2.0003722 **



Viewfinder Bracket for Sony PXW-FS7/ FS7 II, K2.0003749 **



Lens Adapter Support LAS-1, K2.0003899 **

Sets for Sony Sony a7s II / Sony a7r II**

Basic Set for Sony a7s II

Consists of:
 Base Plate for Sony a7s II
 Lens Adapter Support LAS-1
 Side Bracket left for Sony a7s II
 Cable Clamp for Sony a7s II
 Cage Top Handle CTH-1
 Support Rods 240 mm (9.4 inch), Ø 15 mm

KK.0010057

K2.0009468
 K2.0003899
 K2.0009440
 K2.0009646
 K2.66227.0
 K2.66253.0

Pro Set for Sony a7s II

Consists of:
 Base Plate for Sony a7s II
 Lens Adapter Support LAS-1
 Side Bracket left for Sony a7s II
 Cable Clamp for Sony a7s II
 Side Bracket right for Sony a7s II
 Cage Top Handle CTH-1
 Support Rods 240 mm (9.4 inch), Ø 15 mm
 Bridge plate adapter for ALEXA Mini (BPA-4)
 Bridge Plate Sled, BPS-2
 Bottom dove-tail plate 300 mm/12 inch
 Rod mounting bracket (RMB-3)
 Viewfinder Cross Pipe

KK.0010079

K2.0009468
 K2.0003899
 K2.0009440
 K2.0009646
 K2.0009455
 K2.66227.0
 K2.66253.0
 K2.0006352
 K2.66260.0
 K2.0000324
 K2.0006186
 K2.0013302



Base Plate for Sony a7s II K2.0009468



Cable Clamp for Sony a7s II K2.0009646



Side Bracket left for Sony a7s II K2.0009440



Side Bracket right for Sony a7s II K2.0009455



Viewfinder Cross Pipe, K2.0013302

**** discontinued items
 no stock available anymore**