


Viewfinder Bracket for Canon EVF K2.0013195

USER MANUAL

Date: 1 April, 2021



Imprint

Copyright © 2016 Arnold & Richter Cine Technik GmbH & Co. Betriebs KG. All rights reserved. No parts of this document may be reproduced without prior written consent of Arnold & Richter Cine Technik GmbH & Co. Betriebs KG. Specifications are subject to change without notice. Errors, omissions, and modifications excepted

ARRI, ALEXA, AMIRA, Master Grip, LDS and LENS DATA SYSTEM are trademarks or registered trademarks of Arnold & Richter Cine Technik GmbH & Co. Betriebs KG. All other brands or products are trademarks or registered trademarks of their respective holders and should be treated as such. Original version.

For further assistance

ARRI Cine + Video Geräte Gesellschaft m.b.H.
Pottendorferstraße 23-25/3/1
A-1120 Vienna Austria
E-mail: service@arri.com
Website: www.arri.com

Scope

This user manual applies to the following product:
K2.0013195 Viewfinder Bracket for Canon EVF

Disclaimer

Before using the products described in this manual, be sure to read and understand all the particular instructions.

Important safety information:

NOTICE

- Make sure, that all single parts are well fastened. Check the locking screws and all mountings before every use.
- Please always make sure that your camera and the accessories are mounted firmly and securely. Check all connections for a tight and secure hold.
- When using on a tripod (optional), please pay attention to the maximal load capacity of the tripod (refer to the manufacturer).

⚠ WARNING!

Danger of suffocation caused by small parts. Keep this device out of the reach of children and pets.

Attaching the Viewfinder Bracket

1. Unscrew the cover screw

Note: This screw is left handed



2. Remove the swing ring



NOTICE

To loosen the screws, please use a cross-point screwdriver PH00 and a Torx 1,3.

3. Remove the swing plate



4. Unscrew the 4 screws and remove the swing arm



5. Unscrew the 4 screws and remove the clamp hinge and the clamp hinge base



6. Use a 2mm allen key to tighten the ARRI Viewfinder Bracket (K2.0013195) to the Canon viewfinder



7. Ready to use



Service contacts

Munich, Germany

Arnold & Richter Cine Technik
+49 89 3809 2121
service@arri.de
Business hours:
Mo. - Fr. 9:00 - 17:00 (CET)

London, Great Britain

ARRI CT Limited
+44 1895 457 051
service@arri-ct.com
Business hours:
Mo. - Thu. 9:00 - 17:30 (GMT)
Fr. 9:00 - 17:00 (GMT)

Burbank, USA

ARRI Inc. West Coast
+1 877 565 2774
service@arri.com
Business hours:
Mo. - Fr. 8:15 - 17:00 (PST)

Mississauga, Canada

ARRI Canada Limited
+1 416 255 3335
service@arri.com
Business hours:
Mo. - Fr. 8:30 - 17:00 (EDT)

Beijing, China

ARRI China Co. Limited
+86 10 5900 9680
service@arrichina.com
Business hours:
Mo. - Fr. 9:00 - 18:00 (CST)

Vienna, Austria

ARRI Cine + Video Geräte Ges.m.b.H.
+43 1 8920107 30
service@arri.at
Business hours:
Mo. - Fr. 9:00 - 17:00 (CET)

Milan, Italy

ARRI Italia S.r.l.
+39 (02) 262 271 75
info@arri.it
Business hours:
Mo. - Fr. 9:00 - 18:00 (CET)

New York, USA

ARRI Inc. East Coast
+1 877 565 2774
service@arri.com
Business hours:
Mo. - Fr. 8:00 - 17:30 (EST)

Hong Kong, China

ARRI Asia Limited
+852 2537 4266
service@arriasia.hk
Business hours:
Mo. - Fr. 10:00 - 18:30 (HKT)

Sydney, Australia

ARRI Australia Pty Ltd
+61 2 9855 4305
service@arri.com.au
Business hours:
Mo. - Fr. 8:00 - 18:00 (AEST)