

Accessories for Sony BURANO / Sony VENICE 1/2



Configuration Overview | 5.2.0 / 2025.04

Sets for Sony BURANO


Basic Cine Set for Sony BURANO, [KK.0050113](#)
includes:
[K2.0049751](#) 1x Top Plate for Sony BURANO
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0017138](#) 1x Bridge Plate Adapter BPA-5
[K2.65264.0](#) 1x 15mm LWS Rod Console
[K2.66253.0](#) 1x Support Rods 240mm/9.4in, 15mm



Basic Broadcast Set for Sony BURANO, [KK.0050114](#), includes:
[K2.0049751](#) 1x Top Plate for Sony BURANO
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0043749](#) 1x Broadcast Shoulder Adapter BSA-1
[K2.65264.0](#) 1x 15mm LWS Rod Console
[K2.66253.0](#) 1x Support Rods 240mm/9.4in, 15mm



Pro Cine Set for Sony BURANO, [KK.0050115](#)
includes:
[K2.0049751](#) 1x Top Plate for Sony BURANO
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0049819](#) 1x Side Bracket Right for Sony BURANO
[K2.0049816](#) 1x Side Bracket Left for Sony BURANO
[K2.0049904](#) 1x Rear Side Bracket Right for Sony BURANO
[K2.0047776](#) 1x NATO Rail Clamp NRC-1
K2.0048324 1x NATO Rail Clamp NRC-2
[K2.0017270](#) 1x Center Camera Handle CCH-4
[K2.0017138](#) 1x Bridge Plate Adapter BPA-5
[K2.66255.0](#) 2x 15mm Reduction Insert
[K2.65264.0](#) 1x 15mm LWS Rod Console
[K2.66253.0](#) 1x Support Rods 240mm/9.4in, 15mm
K2.0006186 1x Rod Mounting Bracket RMB-3



Pro Broadcast Set for Sony BURANO, [KK.0050116](#), includes:
[K2.0049751](#) 1x Top Plate for Sony BURANO
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0049819](#) 1x Side Bracket Right for Sony BURANO
[K2.0049816](#) 1x Side Bracket Left for Sony BURANO
[K2.0049904](#) 1x Rear Side Bracket Right for Sony BURANO
[K2.0047776](#) 1x NATO Rail Clamp NRC-1
K2.0048324 1x NATO Rail Clamp NRC-2
[K2.0017270](#) 1x Center Camera Handle CCH-4
[K2.0043749](#) 1x Broadcast Shoulder Adapter BSA-1
[K2.66255.0](#) 2x 15mm Reduction Insert
[K2.65264.0](#) 1x 15mm LWS Rod Console
[K2.66253.0](#) 1x Support Rods 240mm/9.4in, 15mm
K2.0006186 1x Rod Mounting Bracket RMB-3



Sets for Sony VENICE 1/2

Basic Cine Set for Sony Venice 1/2, [KK.0043758](#)
includes:
[K2.0043699](#) 1x Top Plate for Sony Venice 1/2
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0017138](#) 1x Bridge Plate Adapter BPA-5
[K2.66252.0](#) 1x Support Rods 340mm/13.4in, 15mm
[K2.0017270](#) 1x Center Camera Handle CCH-4
Center Camera Handle CCH-4



Basic Broadcast Set for Sony Venice 1/2, [KK.0043757](#), includes:
[K2.0043699](#) 1x Top Plate for Sony Venice 1/2
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0043749](#) 1x Broadcast Shoulder Adapter BSA-1
[K2.0017270](#) 1x Center Camera Handle CCH-4
[K2.66252.0](#) 1x Support Rods 340mm/13.4in, 15mm




Pro Cine Set for Sony Venice 1/2, [KK.0043759](#)
includes:
[K2.0043699](#) 1x Top Plate for Sony Venice 1/2
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0017138](#) 1x Bridge Plate Adapter BPA-5
[K2.66252.0](#) 1x Support Rods 340mm/13.4in, 15mm
[K2.0017270](#) 1x Center Camera Handle CCH-4
[K2.0043731](#) 1x Side Bracket Right for Sony Venice 1/2
[K2.0043725](#) 1x Side Bracket Left for Sony Venice 1/2
[K2.0021525](#) 1x EVF Bracket for Sony DVF-EL200 (Venice)
[K2.0006140](#) 1x Mini Viewfinder Bracket MVB-1



Pro Broadcast Set for Sony Venice 1/2, [KK.0043753](#), includes:
[K2.0043699](#) 1x Top Plate for Sony Venice 1/2
[K2.0043726](#) 1x Plate for Sony Venice 1/2
[K2.0043749](#) 1x Broadcast Shoulder Adapter BSA-1
[K2.66252.0](#) 1x Support Rods 340mm/13.4in, 15mm
[K2.0017270](#) 1x Center Camera Handle CCH-4
[K2.0043731](#) 1x Side Bracket Right for Sony Venice 1/2
[K2.0043725](#) 1x Side Bracket Left for Sony Venice 1/2
[K2.0021525](#) 1x EVF Bracket for Sony DVF-EL200 (Venice)
[K2.0006140](#) 1x Mini Viewfinder Bracket MVB-1



Parts for Sony BURANO



Top Plate for Sony BURANO
[K2.0049751](#)



NATO Rail Clamp NRC-1
[K2.0047776](#)



NATO Rail Clamp RC-2
K2.0048324



Side Bracket Left for Sony BURANO
[K2.0049816](#)



Side Bracket Right for Sony BURANO,
[K2.0049819](#)



Rear Side Bracket Right for
Sony BURANO, [K2.0049904](#)

Parts for Sony VENICE 1/2



Top Plate for Sony Venice 1/2
[K2.0043699](#)



Plate for Sony Venice 1/2
[K2.0043726](#)



Broadcast Shoulder Adapter
BSA-1, [K2.0043749](#)



Side Bracket Right for Sony Venice 1/2
[K2.0043731](#)



Side Bracket Left for Sony Venice 1/2
[K2.0043725](#)



Rosette Adapter RA-6 (pair)
[K2.0024574](#)