

# Stabilizer System - Cable Guide 2



## Configuration Overview | 8.6.1 / 2024.08

| Item Number                | Cable Name                                          | Supported Cameras                                                                                                                                                                                            | Artemis 1 | Artemis 2 | TRINITY 1               | TRINITY 2 | 360 EVO |
|----------------------------|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|-----------|-------------------------|-----------|---------|
| <a href="#">K2.0010546</a> | Monitor Power, 12V, Lemo 0B 2-pin                   | 12V monitor power cable. Lemo 0B 2-pin to XLR 4-pin, 12V.                                                                                                                                                    | ✓         | ✓         | ✓                       | ✓         | ✓       |
| <a href="#">K2.0041723</a> | Monitor Power, 12V, Lemo 0B 2-pin to 0B 2-pin       | Short 12 V power cable to power a second Transvideo Starlite or SmallHD monitor from the Tally System Gen.2 host module. Lemo 0B 2-pin to Lemo 0B 2-pin, 12V                                                 | ✓         | ✓         | ✓                       | ✓         | ✓       |
| <a href="#">K2.0021422</a> | 12V Battery Power Cable, D-Tab, 4-pin XLR, 1,5m/5ft | 12 V power cable to power the 360 EVO, SRH-3 and SRH-360 remote control panel, or a monitor via D-Tab. D-Tab to 4-pin XLR, 1,5m/5ft, 12V. For Remote Control Panel (RCP-2) of the 360 EVO, SRH-3 and SRH-360 | ✓         | ✓         | ✓                       | ✓         | ✓       |
| <a href="#">K2.0038998</a> | MTG Monitor Pwr, Lemo 0B, 2-pin                     | Power cable to power a Transvideo Starlight, or SmallHD 503 monitor from the Master Grip TRINITY 2. Lemo 0B 4-pin to Lemo 0B 2-pin, 24V. For MGT-1, MGT-2, TRINITY 2                                         | ✗         | ✗         | ✓<br>after LBUS upgrade | ✓         | ✗       |
| <a href="#">K2.0038999</a> | MTG Monitor Pwr, Lemo 0B, 5-pin                     | Power cable to power a ARRI Starlite monitor from the Master Grip TRINITY 2. Lemo 0B 4-pin to Lemo 0B 5-pin, 24V. For MGT-1, MGT-2, TRINITY 2                                                                | ✗         | ✗         | ✓<br>after LBUS upgrade | ✓         | ✗       |
| <a href="#">K2.0043861</a> | TRINITY 2 Joystick Cable, 75cm/29.5in               | Flexible joystick cable to connect Master Grip TRINITY with the TRINITY 2 head. Lemo 0B 4-pin to Lemo 0B 4-pin, 24V, 75cm/29.5in                                                                             | ✗         | ✗         | ✓<br>after LBUS upgrade | ✓         | ✗       |
| <a href="#">K2.0043975</a> | TRINITY 2 Joystick Cable, 1,25m/49in                | Flexible joystick cable to connect the Master Grip TRINITY to the TRINITY 2 head when the rig is fully extended or when using a Super Post. Lemo 0B 4-pin to Lemo 0B 4-pin, 24V, 125cm/49in                  | ✗         | ✗         | ✓<br>after LBUS upgrade | ✓         | ✗       |
| <a href="#">K2.0043884</a> | TRINITY 2 analog Joystick Cable                     | Analog joystick cable to connect the analog TRINITY Gen. 1 Joystick with TRINITY 2. Lemo 1B 8-pin to Lemo 0B 7-pin, no video, 12V                                                                            | ✗         | ✗         | ✓                       | ✓         | ✗       |
| <a href="#">K2.0014805</a> | TRINITY Gen. 1 Joystick Main Cable                  | TRINITY Gen. 1 Joystick Main Cable including the BNC-SMB Cable. Lemo 1B 8-pin to Lemo 0B 7-pin, 12V                                                                                                          | ✗         | ✗         | ✓                       | ✗         | ✗       |
| <a href="#">K2.0014801</a> | Joystick Pwr. Cable for ARRI Starlite               | Power cable to connect the ARRI Starlight monitor to the TRINITY Gen.1 Joystick Monitor Mount. Lemo 0B 5-pin 90° elbow to Lemo 0B 5-pin, 12V                                                                 | ✗         | ✗         | ✓                       | ✗         | ✗       |
| <a href="#">K2.0014803</a> | Joystick Pwr. Cable for Starlite                    | Power cable to connect the Transvideo Starlight, or Small HD 503 monitor to the TRINITY Gen. 1 Joystick Monitor Mount. Lemo 0B 5-pin 90° elbow to Lemo 0B 2-pin, 12V                                         | ✗         | ✗         | ✓                       | ✗         | ✗       |