

Handgrips & Accessories



Configuration Overview | 5.5.0 / 2025.05

Top Handles



Cage Top Handle
CTH-1, [K2.66227.0](#)



Cage Top Handle
CTH-2, [K2.0054160](#)



Lightweight Camera
Handle LCH-1,
[K2.0024066](#)



Camera Center
Handle CCH-4,
[K2.0017270](#)



Center Camera
Handle CCH-2,
[K2.73002.0](#)

Handle Support



Handle Extension Set, [KK.0037820](#)
includes:
[K2.0019791](#) 1x Handle Extension HEX-1
[K2.0019792](#) 1x Handle Extension HEX-2
[K2.0019797](#) 1x Handle Extension HEX-3
[K2.0019798](#) 1x Handle Extension HEX-4
[K2.0036917](#) 1x Handle Extension HEX-5
[K2.0019810](#) 1x Handle Extension HEX-90
[K2.0037131](#) 1x Wooden Shell for HEX
[K2.0037132](#) 1x Plastic Shell for HEX



Handle Extension Set for ALEXA 35,
[KK.0051730](#), includes:
[K2.0019791](#) 1x Handle Extension HEX-1
[K2.0019792](#) 1x Handle Extension HEX-2
[K2.0019797](#) 1x Handle Extension HEX-3
[K2.0019798](#) 1x Handle Extension HEX-4
[K2.0036917](#) 1x Handle Extension HEX-5
[K2.0019810](#) 1x Handle Extension HEX-90
[K2.0037131](#) 1x Wooden Shell for HEX
[K2.0049050](#) 1x Handle Extension HEX-A



Handle Extension
HEX-1, [K2.0019791](#)



Handle Extension
HEX-2, [K2.0019792](#)



Handle Extension
HEX-3, [K2.0019797](#)



Handle Extension
HEX-4, [K2.0019798](#)



Handle Extension
HEX-5, [K2.0036917](#)



Handle Extension
HEX-90, [K2.0019810](#)



Handle Extension
HEX-A, [K2.0049050](#)



Handle Extension Block,
HEB-1, [K2.0001016](#)



Handle Extension Block
long, HEB-3, [K2.0001017](#)



CCH-2 Support,
[K2.0038176](#)



Wooden Shell for HEX
[K2.0037131](#)



Plastic Shell for HEX
[K2.0037132](#)



Bicycle Grip Adapter
BGA-1, [K2.0034248](#)



Bicycle Grip Adapter
BGA-2, [K2.0036623](#)

Handgrip Sets and Parts



UBS-3 Handgrip Set without on/off,
[KK.0005675](#), includes:
[K2.47861.0](#) 2x Handgrip without on/off switch
[K2.47863.0](#) 2x Handgrip Extension, long
[K2.0013320](#) 1x Universal Bridge Support UBS-3



LBS-2 Handgrip Set without on/off,
[KK.0005674](#), includes:
[K2.47861.0](#) 2x Handgrip without on/off switch
[K2.47863.0](#) 2x Handgrip Extension, long
[K2.66275.0](#) 1x Lightweight Bridge Support LBS-2



UBS-3 Handgrip Set on/off RS 3-pin,
[KK.0005677](#), includes:
[K2.47861.0](#) 1x Handgrip without on/off switch
[K2.47862.0](#) 1x Handgrip with on/off switch RS-3 pin
[K2.47863.0](#) 2x Handgrip Extension, long
[K2.0013320](#) 1x Universal Bridge Support UBS-3



LBS-2 Handgrip Set on/off RS 3-pin
[KK.0005676](#), includes:
[K2.47861.0](#) 1x Handgrip without on/off switch
[K2.47862.0](#) 1x Handgrip with on/off switch RS-3 pin
[K2.47863.0](#) 2x Handgrip Extension, long
[K2.66275.0](#) 1x Lightweight Bridge Support LBS-2



Handgrip Set Right,
[KK.0005710](#), includes:
[K2.45886.0](#) 1x Standard righthand articulating Handgrip
[K2.47863.0](#) 1x Handgrip Extension, long



Wooden Handgrip WHG-3 right,
[K2.0054216](#)



Wooden Handgrip WHG-3 left,
[K2.0054215](#)




Wooden Handgrips
WHG-2 (Pair)
[K2.0052124](#)



Mountable Run Stop Button
MRS-1, [K2.0045006](#)



Cable RRS-1 (0.8m/2.6ft)
[K2.0051326](#)



Cable RS/PWR IN - LANC
[K2.0049984](#)



Handgrip without
on/off switch,
[K2.47861.0](#)



Handgrip with on/
off switch RS-3 pin,
[K2.47862.0](#)



Handgrip with on/off
switch Hirose 4-pin,
[K2.66278.0](#)



Standard Grip Left
SGL-1, [K2.0016317](#)



Standard Grip Right
SGR-1, [K2.0016318](#)



Standard righthand
articulating Handgrip
[K2.45886.0](#)

Handgrip Support



Rosette Extension REX-40 Set
[KK.0049433](#), Includes:
[K2.0048099](#) 1x Rod Clamp for REX-40
[K2.0049430](#) 1x Rosette Extension REX-40
[K2.66255.0](#) 1x 15mm Reduction Insert



Rosette Extension REX-25,
[K2.0048040](#)



Rosette Extension
REX-40, [K2.0049430](#)



Rod Clamp for
REX-40, [K2.0048099](#)



Extension Tube
[K2.47136.0](#)



Extension Spacer
50 mm, [K2.0013615](#)



15 mm Cable Clip
[K2.0012921](#)



Handgrip Extension
80 mm, [K2.0012913](#)



Handgrip Extension
160 mm, [K2.0012911](#)



Handgrip Extension
240 mm, [K2.0012917](#)