

## Top Handles



Cage Top Handle CTH-1, [K2.66227.0](#)



Cage Top Handle CTH-2, [K2.0054160](#)



Lightweight Camera Handle LCH-1, [K2.0024066](#)



Camera Center Handle CCH-4, [K2.0017270](#)



Center Camera Handle CCH-2, [K2.73002.0](#)

## Handle Support

### Handle Extension Set, KK.0037820 includes:

- [K2.0019791](#) 1x Handle Extension HEX-1
- [K2.0019792](#) 1x Handle Extension HEX-2
- [K2.0019797](#) 1x Handle Extension HEX-3
- [K2.0019798](#) 1x Handle Extension HEX-4
- [K2.0036917](#) 1x Handle Extension HEX-5
- [K2.0019810](#) 1x Handle Extension HEX-90
- [K2.0037131](#) 1x Wooden Shell for HEX
- [K2.0037132](#) 1x Plastic Shell for HEX



### Handle Extension Set for ALEXA 35, KK.0051730, includes:

- [K2.0019791](#) 1x Handle Extension HEX-1
- [K2.0019792](#) 1x Handle Extension HEX-2
- [K2.0019797](#) 1x Handle Extension HEX-3
- [K2.0019798](#) 1x Handle Extension HEX-4
- [K2.0036917](#) 1x Handle Extension HEX-5
- [K2.0019810](#) 1x Handle Extension HEX-90
- [K2.0037131](#) 1x Wooden Shell for HEX
- [K2.0049050](#) 1x Handle Extension HEX-A



Handle Extension HEX-1, [K2.0019791](#)

Handle Extension HEX-2, [K2.0019792](#)

Handle Extension HEX-3, [K2.0019797](#)

Handle Extension HEX-4, [K2.0019798](#)

Handle Extension HEX-5, [K2.0036917](#)

Handle Extension HEX-90, [K2.0019810](#)

Handle Extension HEX-A, [K2.0049050](#)

Handle Extension Block, HEB-1, [K2.0001016](#)

Handle Extension Block long, HEB-3, [K2.0001017](#)

CCH-2 Support, [K2.0038176](#)

Wooden Shell for HEX [K2.0037131](#)

Plastic Shell for HEX [K2.0037132](#)

Bicycle Grip Adapter BGA-1, [K2.0034248](#)

Bicycle Grip Adapter BGA-2, [K2.0036623](#)

## Handgrip Sets and Parts

**UBS-3 Handgrip Set** without on/off, [KK.0005675](#), includes:  
[K2.47861.0](#) 2x Handgrip without on/off switch  
[K2.47863.0](#) 2x Handgrip Extension, long  
[K2.0013320](#) 1x Universal Bridge Support UBS-3



**LBS-2 Handgrip Set** without on/off, [KK.0005674](#), includes:  
[K2.47861.0](#) 2x Handgrip without on/off switch  
[K2.47863.0](#) 2x Handgrip Extension, long  
[K2.66275.0](#) 1x Lightweight Bridge Support LBS-2



**UBS-3 Handgrip Set on/off RS 3-pin**, [KK.0005677](#), includes:  
[K2.47861.0](#) 1x Handgrip without on/off switch  
[K2.47862.0](#) 1x Handgrip with on/off switch RS-3 pin  
[K2.47863.0](#) 2x Handgrip Extension, long  
[K2.0013320](#) 1x Universal Bridge Support UBS-3



**LBS-2 Handgrip Set on/off RS 3-pin**, [KK.0005676](#), includes:  
[K2.47861.0](#) 1x Handgrip without on/off switch  
[K2.47862.0](#) 1x Handgrip with on/off switch RS-3 pin  
[K2.47863.0](#) 2x Handgrip Extension, long  
[K2.66275.0](#) 1x Lightweight Bridge Support LBS-2



**Handgrip Set Right**, [KK.0005710](#), includes:  
[K2.45886.0](#) 1x Standard righthand articulating Handgrip  
[K2.47863.0](#) 1x Handgrip Extension, long



Wooden Handgrip WHG-3 right, [K2.0054216](#)

Wooden Handgrip WHG-3 left, [K2.0054215](#)

Wooden Handgrips WHG-2 (Pair) [K2.0052124](#)

Mountable Run Stop Button MRS-1, [K2.0045006](#)

Cable RRS-1 (0.8m/2.6ft) [K2.0051326](#)

Cable RS/PWR IN - LANC [K2.0049984](#)



Handgrip without on/off switch, [K2.47861.0](#)



Handgrip with on/off switch RS-3 pin, [K2.47862.0](#)



Handgrip with on/off switch Hirose 4-pin, [K2.66278.0](#)



Standard Grip Left SGL-1, [K2.0016317](#)



Standard Grip Right SGR-1, [K2.0016318](#)



Standard righthand articulating Handgrip [K2.45886.0](#)

## Handgrip Support



**Rosette Extension REX-40 Set** [KK.0049433](#), Includes:  
[K2.0048099](#) 1x Rod Clamp for REX-40  
[K2.0049430](#) 1x Rosette Extension REX-40  
[K2.66255.0](#) 1x 15mm Reduction Insert



Rosette Extension REX-25, [K2.0048040](#)



Rosette Extension REX-40, [K2.0049430](#)



Rod Clamp for REX-40, [K2.0048099](#)



Extension Tube [K2.47136.0](#)



Extension Spacer 50 mm, [K2.0013615](#)



15 mm Cable Clip [K2.0012921](#)



Handgrip Extension 80 mm, [K2.0012913](#)



Handgrip Extension 160 mm, [K2.0012911](#)



Handgrip Extension 240 mm, [K2.0012917](#)