

Set for Panasonic AU-EVA1

Basic Set for Panasonic AU-EVA1 [KK.0016260](#)

Consists of:	
Plate for Panasonic AU-EVA1	K2.0015883
Top Plate for Panasonic AU-EVA1	K2.0015880
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0

Pro Set for Panasonic AU-EVA1 [KK.0016261](#)

Consists of:	
Plate for Panasonic AU-EVA1	K2.0015883
Top Plate for Panasonic AU-EVA1	K2.0015880
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Monitor Bracket for Panasonic AU-EVA1	K2.0016259
HGA-3 for Panasonic AU-EVA1	K2.0016711
Battery Adapter Plate BAP-1	K2.0006471
15 mm LWS Rod Console	K2.65264.0
Support Rods 140 mm (5.5 inch), Ø 15 mm (2x)	K2.66254.0



Plate for Panasonic AU-EVA1 [K2.0015883](#)



Top Plate for Panasonic AU-EVA1 [K2.0015880](#)



Monitor Bracket for Panasonic AU-EVA1, [K2.0016259](#)



HGA-3 for Panasonic AU-EVA1 [K2.0016711](#)

Set for Panasonic VariCam 35/HS

Set for Panasonic VariCam 35/HS ** [KK.0006721](#)

Consists of:	
Adapter Plate for Panasonic VariCam 35/HS	K2.0003420
Top/Side Plate for Panasonic VariCam 35/HS	K2.0003424
15 mm Rods 240 mm	K2.66253.0



Adapter Plate for VariCam 35/HS, [K2.0003420](#) **



Top / Side Plate for VariCam 35/HS, [K2.0003424](#) **

Set for Panasonic VariCam LT

Basic Set for Panasonic VariCam LT [KK.0010061](#)

Consists of:	
Plate for VariCam LT	K2.0009593
Top plate for VariCam LT	K2.0009694
Center Camera Handle, CCH-2	K2.73002.0
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0

Broadcast Pro Set for Panasonic VariCam LT [KK.0010074](#)

Consists of:	
Plate for VariCam LT	K2.0009593
Top plate for VariCam LT	K2.0009694
Center Camera Handle, CCH-2	K2.73002.0
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Quick Release Plate, QRP-1	K2.0000399

Cine 19mm Pro Set for Panasonic VariCam LT [KK.0010077](#)

Consists of:	
Plate for VariCam LT	K2.0009593
Top plate for VariCam LT	K2.0009694
Center Camera Handle, CCH-2	K2.73002.0
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Bridge Plate BP-8 Set (19 mm Rods)	K2.47090.0

Cine 15mm Pro Set for Panasonic VariCam LT [KK.0010075](#)

Consists of:	
Plate for VariCam LT	K2.0009593
Top plate for VariCam LT	K2.0009694
Center Camera Handle, CCH-2	K2.73002.0
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Bridge Plate BP-9 Set (15mm Rods)	K2.47091.0



Adapter Plate for Plate for VariCam LT, [K2.0009593](#)



Top Plate for VariCam LT, [K2.0009694](#)



Viewfinder Bracket for VariCam, [K2.0010580](#)

** discontinued items
no stock available anymore

Sets for RED DSMC2

Pro Cine Set 19 mm for RED DSMC2 [KK.0010059](#)

Consists of:	
Cine plate for RED DSMC2	K2.0008886
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Support Rods 140 mm (5.5 inch), Ø 15 mm	K2.66254.0
Bridge Plate Sled, BPS-2	K2.66260.0
Bottom dove-tail plate 300 mm/12 inch	K2.0000324
Top plate for RED DSMC2	K2.0009664
Top handle for RED DSMC2	1K2.0008903
Monitor bracket for RED DSMC2	K2.0009582

Pro Cine Set 19 mm for RED DSMC2 [KK.0010066](#)

Consists of:	
Cine plate for RED DSMC2	K2.0008886
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Support Rods 140 mm (5.5 inch), Ø 15 mm	K2.66254.0
Top plate for RED DSMC2	K2.0009664
Top handle for RED DSMC2	K2.0008903
Monitor bracket for RED DSMC2	K2.0009582
Bridge Plate BP-8 Set (19 mm Rods)	K2.47090.0

Pro Cine Set 15 mm for RED DSMC2 [KK.0010068](#)

Consists of:	
Cine plate for RED DSMC2	K2.0008886
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Support Rods 140 mm (5.5 inch), Ø 15 mm	K2.66254.0
Top plate for RED DSMC2	K2.0009664
Top handle for RED DSMC2	K2.0008903
Monitor bracket for RED DSMC2	K2.0009582
Bridge Plate BP-9 Set (15 mm Rods)	K2.47091.0

Broadcast Set for RED DSMC2 [KK.0010069](#)

Consists of:	
Broadcast plate for RED DSMC2	K2.0009614
Support Rods 240 mm (9.4 inch), Ø 15 mm	K2.66253.0
Quick Release Plate, QRP-1	K2.0000399
Top plate for RED DSMC2	K2.0009664
Top handle for RED DSMC2	K2.0008903
Monitor bracket for RED DSMC2	K2.0009582



Cine Plate for RED DSMC2, [K2.0008886](#)



Top Plate for RED DSMC2, [K2.0009664](#)



Broadcast Plate for RED DSMC2, [K2.0009614](#)



Top Handle for RED DSMC2, [K2.0008903](#)



Monitor Bracket for RED DSMC2, [K2.0009582](#)



Viewfinder Bracket for RED DSMC2, [K2.0008712](#)

Brackets for Electronic Viewfinders

EVF bracket set for Zacuto Gratical [KK.0010048](#)

Consists of:	
Viewfinder mounting bracket for ALEXA Mini (MVB-1)	K2.0006140
EVF bracket for Zacuto Gratical	K2.0008624

EVF bracket set for Small HD Sidefinder [KK.0010056](#)

Consists of:	
Viewfinder mounting bracket for ALEXA Mini (MVB-1)	K2.0006140
EVF bracket for Small HD Sidefinder	K2.0008711

EVF bracket set for Canon Monitor Unit [KK.0010060](#)

Consists of:	
Viewfinder mounting bracket for ALEXA Mini (MVB-1)	K2.0006140
EVF bracket for Canon Monitor Unit	K2.0008955

EVF bracket set for VariCam [KK.0012560](#)

Consists of:	
Viewfinder mounting bracket for ALEXA Mini (MVB-1)	K2.0006140
EVF bracket for VariCam	K2.0010580

EVF bracket set for RED Bomb Viewfinder [KK.0012695](#)

Consists of:	
Viewfinder mounting bracket for ALEXA Mini (MVB-1)	K2.0006140
EVF bracket for RED Bomb Viewfinder	K2.0008712

EVF bracket set for RED DSMC2 [KK.0012693](#)

Consists of:	
Viewfinder mounting bracket for ALEXA Mini (MVB-1)	K2.0006140
EVF bracket for RED DSMC2	K2.0012522



Viewfinder Bracket for VariCam, [K2.0010580](#)



EVF bracket for Zacuto Gratical, [K2.0008624](#)



EVF bracket for Small HD Sidefinder, [K2.0008711](#)



EVF bracket for Canon Monitor Unit, [K2.0008955](#)



Viewfinder Bracket for RED Bomb, [K2.0008712](#)



Viewfinder Bracket for Canon C700, [K2.0013195](#)



Viewfinder Bracket for RED DSMC2, [K2.0012522](#)