WRS cables

CONFIGURATION OVERVIEW - 5.6.0 / 2013.12

© 2010 Arnold & Richter Cine Technik GmbH & Co. Betriebs KG. All rights reserved. This material is provided "as is" for information purposes only without any warranty. ARRI assumes no responsibility with regard to the performance or use of the products or typographical errors or inaccuracies of given information. Product specifications are subject to change without notice. For a full listing of all available components consult the price list.

PSC cable	ARRI cable WRC-2	ARRI cable UMC-3	
		K2.65239.0 K2.65012.0	UMC Connection Cable K-UMC3-ALE UMC-3/AUX Cooke S4i lens (0,4m/1,2 Connects AUX socket on UMC-3 to Cool
		K2.65013.0	Functions: transfers lens data from Cook UMC-3 to 235 cable (0,4m/1,2ft) KC-9 Connects CAM socket on UMC-3 to REM
ARRI PSC cables UMC-3A K2.65214.0 UMC-3A PSC 12 V		K2.65014.0	Functions: RUN/STOP trigger, RUN indic UMC-3 to RS cable (0,5m/1,7ft) KC-98 Connects CAM socket on UMC-3 to RS s Functions: RUN/STOP trigger, RUN indic
K2.65204.0 External Battery Cable for UMC-3A and Video Cameras K2.65186.0 UMC-3A / CAM / RED - PSC K2.65204.0 UMC-3A - Video (Hirose 12p) - PSC (Y-cable) K2.65205.0 UMC-3A - SONY F35 - PSC (Y-cable) UMC-3A	** WRC-2	K2.65015.0	UMC-3 to CAM cable (1m/3ft) KC-99-5 "Y" cable that connects CAM socket on 435 Advanced (with FEM-1 or FEM-2), 43
K2.65235.0 UMC-3A - Video-RS - PSC (Y-cable) K2.65270.0 UMC-3A - IF for Epic - PSC (0,7 m) K2.65215.0 UMC-3A PSC RS232 Update Cable K2.0000321 UMC-3A to Sony F5/F55	K4.41395.0LCS (3,5m/11ft) K-LC-Z1-SK2.41396.0LCS (7m/23ft) LC-Z2K4.41397.0LCS (1m/3ft) K-LC-M1	UMC-3A K2.65034.0	Functions: RUN/STOP trigger, RUN indic UMC-3 to MOVIECAM cable (0,5m/1,5 "Y" cable that connects CAM socket on socket on MOVIECAM cameras
	K2.65010.0 LCS (2m/6ft) K-LC-M2 LCS cables connect from WHA-2 or WHA-3 with WRC-2)	K2.65035.0	Functions: RUN/STOP trigger. Cannot ca UMC-3 to XTR cable (0,5m/1,5ft) KC 1 Connects CAM socket on UMC-3 to 8 pin Eurotions: PLIN/STOP trigger. PLIN india
ARRI PSC cables WCU-3 K2.65216.0 WCU-3 PSC Update Cable with CAN Dongle	K4.47329.0 RCU cable (1,5m/5ft) KC-39 connects to ARRIFLEX K4.47350.0 RCU cable (20m/60ft) KC-41	K2.65042.0	Functions: RUN/STOP trigger, RUN indic UMC-3 to 11 pin Fischer cable (0,5/1,5 Connects CAM socket on UMC-3 to 11 p and all models of 435
K2.65226.0	 connects to ARRIFLEX K2.65139.0 CAC cable (1,5/5ft) KC-125S connects to ARRICAM K2.65149.0 LCS cable (1,5/5ft) KC-126S 	K2.65057.0	Functions: RUN/STOP trigger, RUN indic UMC-3 to Fujinon ENG lens cable KC Y-Cable connects to ports on handgrip m and zoom using ARRI WRS control units
CLM-2/3 motor control via ZMU-3(A) (1m/3ft) Power supply through ARRI PSC* system connector Camera Run function with ALEXA, 235, all 435, 535, 16SRIII, ARRICAM	K2.65153.0connects to LCS Connector cable (1,5/5ft) KC-128S connects to Sony F23/F35	K2.65060.0	right-angle plugs to clear lightweight sup UMC-3 to A-Minima cable (0,5m/1,5ft Connects CAM socket on UMC-3 to 6 pin Functions RUN/STOP trigger, RUN indica CAM socket on UMC-3 to 6 pin LEMO so
Replaces: KC 91-S & KC 117-S in combination with the appropriate PSC*power supply cable		K2.65063.0	UMC-3 / AUX CTM Lemo 6p (Spiral) K Connects AUX socket to Cine Tape Meas
K2.65237.0ZMU-3ACable ZMU-3 RED-PSC* (0,6m/2ft)Power supply through ARRI PSC* system connector		K2.65074.0	UMC-3 to Canon ENG lens cable KC 1 Connects to port on handgrip motor of C using ARRI WRS control units, as well as
Camera REC function. connects ZMU-3(A) to RED camera		K2.65063.0	angle plugs to clear lightweight support UMC-3 / CAM CTM Lemo 6p (Spiral - a Connects CAM socket to Cine Tape Mea
	** discontinued items no stock available anymore	K4.41395.0 K4.52096.0 K2.65187.0	ARRI LCS cable 3,5m (11ft) K-LC-Z1-S ARRI LCS spiral cable K-LC-M1-Sp-S UMC-3A to Anton Bauer D-Tap
PSC power cable	ARRI cable WRS		
PSC Cable System: Both needed: upper part: PSC cable		ARRI cable WCU-3	
lower part: PSC power cable		K4.41395.0 K4.41397.0 K2.65159.0 K2.65009.0 K2.65010.0 K2.41389.0	LCS (3,5m/11ft) K-LC-Z1-S LCS sprial cable K-LC-M1-Sp-S WCU-3 to ZMU-3(A) cable (0,25m/0,8 LCS to ZMU-3(A) cable (0,8m/2,5ft) K0 LCS to ZMU-3(A) (10m/33ft) KC 93-S Cable Drum Extension (75m/250ft) LC
* ARRI PSC power supply cables K2.65206.0 PSC-XLR3 1,5m/5ft 1,5m/5ft 24volts battery K2.65207.0 PSC-XLR4 1,5m/5ft 1,5m/5ft 12volts battery	** WMU-3 K2.52270.0 WMU-3 Update cable (2m/7ft)		
K2.65208.0 PSC-DTAP 0,6m/2ft 0,6m/2ft Anton Bauer D-Tap socket K2.65209.0 PSC-HI12 0,6m/2ft 0,6m/2ft Hirose 12pin socket	KC87-S K2.52096.0 Cable WC-A2S antenna extension cable 3m	ARRI cable ZMU-3	
K2.65210.0 PSC-FI11 0,6m/2ft 0,6m/2ft ARRIFLEX 435, SONY F23/F35 K2.65211.0 PSC-RS 0,6m/2ft 0,6m/2ft ARRI RS socket K2.65212.0 PSC-FI2 0,6m/2ft 1,5m/5ft ARRI OBB-2 battery K2.65213.0 PSC-LCS 0,6m/2ft 0,6m/2ft ARRI LCS bus	K2.52263.0 Cable WC-A3-S for wired con- nection of two radio units 15m K4.52336.0 Cable WC-E1-S K2.52084.0 Cable WC-E2-S	K2.65159.0 K2.65009.0 K2.65010.0 K2.65059.0	Cable ZMU-3 - LCS (0,258m/0,8ft) KC Cable ZMU-3 - LCS (0,8m/2.6ft) KC 92 Cable ZMU-3 - LCS (10m/33ft) KC 93- Cable ZMU-3 - LCS (30m/100ft) KC 11
		ZMU-3A	Cable 2100-3 - 203 (30m/10011) KC 11.



LEXA 1,2ft) KC-96-S ooke S4i lenses ooke S4i lenses C-97-S REMOTE socket on ARRIFLEX 235 or 416 dication, ASYNC indication, camera remote control with WRC-2 -98-S RS socket on ARRU cameras dication, ASYNC indication 99-S on UMC-3 to ACC and CCU socketon ARRIFLEX 535, 535B, 435ES, , 435 Xtreme and all 16 SR 3 models. dication, ASYNC indication, camera remote control with WRC-2 /1,5ft) KC 103-S on UMC-3 to 24V SERVICE (2 pin accessory power) and REMOTE carry WRC-2 camera control signals C 104-S pin LEMO socket on Aaton XTR dication. Cannot carry WRC-2 camera control signals /1,5 ft) KC 108-S 1 pin Fischer (12 V supply) socket on many older (black) ARRI cameras dication. Cannot carry WRC-2 camera control signals KC 110-S p motor of Fujinon ENG lens. Allows for remote control of focus iris nits, as well as camera RUN/STOP. Cable-to-lens connectors via special support rods. 5ft) KC 113-S pin LEMO socket on Aaton A-Minima dication. Cannot carry WRC-2 camera control signals. Also connects socket on Aaton XTR. Functions: RUN/STOP trigger KC 116-SP-S easure units C 118-S of Canon ENG lens. Allows for remote control of focus, iris and zoom I as camera RUN/STOP. Cable-to-lens connectors via special rightort rods - available on request KC 119-Sp-S leasure units, power supply via LCS connector 1-S S

0,8ft)) KC 92-S -S I LC-E1 LCS

KC 129-S, Connects ZMU-3(A) to LCS - Bus (WCU-3) 92-S, Connects ZMU-3(A) to LCS - Bus 93-S, connects ZMU-3(A) to LCS - Bus 112-S, connects ZMU-3(A) to LCS - Bus