ALEXA 35 Live - Multicam System - LPS-1 Fiber Camera Adapter - Connectors

Configuration Overview | 2.2.1 / 2024.05

Connectors	
HEADSET	XLR 5-pin socket for intercom headset
A OUT	XLR 3-pin plug for AES or analog line audio out
A1 IN	XLR 3-pin socket for audio input 1 (MIC 48V/MIC/LINE/AES)
A2 IN	XLR 3-pin socket for audio input 2 (MIC 48V/MIC/LINE/AES)
FIBER	Lemo 3K SMPTE 311M fiber connector (socket)
AUX FIBER	Neutrik Opticon connector for auxiliary fiber tunnel
12V/4A	Lemo EGG socket for 12V accessory power output*
12V/2A	Lemo EGG socket for 12V accessory power output
24V/4A	ARRI RS Lemo socket for 24V accessory power output*

Connectors	
GPIO	Hirose 10-pin HR10A connector
TRACKER	Hirose 20-pin HR10A connector
SDI1 OUT	BNC Monitor out (= ALEXA 35 SDI 1 out)
RET OUT	BNC Monitor output of return video in from Fiber Base Station
RCP PoE	RJ45 Ethernet for direct RCP connection
ETH	RJ45 for auxiliary 1 Gbit/s Ethernet tunnel
LLA PoE	RJ45 Ethernet for Large Lens Adapter interface module for future use
REF OUT	BNC Genlock out
AUX	BNC Auxiliary/Teleprompter SDI out

© 2026 Arnold & Richter Cine Technik GmbH & Co. Betriebs KG. All rights reserved. This material is provided "as is" for information purposes only without any warranty. ARRI assumes no responsibility with regard to the performance or use of the products or typographical errors or inaccuracies of given information. Product specifications are subject to change without notice. For a full listing of all available components consult the price list.