Mounting the Direct Mount



Vibration Isolator for SRH

Mounting the Mitchell Mount Adapter



Mounting the Mitchell Mount Adapter

1.	2.	3.	4.
Remove the Castle Nut first to reach the six Hex screws.	Place the SRH Mitchell Mount on the base of the pan axis. Check the alinement of the location pin, before tighten all six Hex screws. Use a 6mm Hex key.	Place the Vibration Isolator on the SRH. Check the alinement of the location pin.	Place and tighten the Castle Nut.
5.	6.		
Remove the Castle Nut of the Vibration Isolator and mount the complete setup to the crane	NOTE Check the alinement of the location pin before tightening the Castle Nut.		

Adjustment

